




**CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S**

Broj dela:	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S
Proizvođač / robna marka:	Schurter
Opis proizvoda	SWITCH PUSHBUTTON SPST 100MA 42V
Datasheets:	 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S.pdf
Status RoHS	 Bez olova / RoHS
Ship From	hong kong
Shipment Way	DHL/Fedex/TNT/UPS/EMS

[REQUEST FOR QUOTATION](#)

Slika može biti reprezentativna. Pogledajte specifikacije za detalje o proizvodu.

Specifikacije CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S

BROJ DELA	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S
PROIZVOĐAČ	Schurter
OPIS	SWITCH PUSHBUTTON SPST 100MA 42V
STATUS BEZ VODE / ROHS STATUS	Bez olova / RoHS
TEHNIČKI LIST	 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S.pdf
VOLTAGE RATING - DC	60V
VOLTAGE RATING - AC	42V
TIP	Capacitive, Illuminated
TERMINATION STYLE	Wire Leads
FUNKCIJA PREKIDAČA	Off-On
SERIES	CPS
DIMENZIJE IZLAZA PANELA	Circular - 19.10mm Dia
PAKOVANJE	Bulk
RADNA TEMPERATURA	-40°C ~ 60°C
TIP MONTAŽE	Panel Mount, Front
NIVO OSETLJIVOSTI NA VLAGU (MSL)	1 (Unlimited)
MEHANIČKI ŽIVOT	-
STATUS BEZ VODE / ROHS STATUS	Lead free / RoHS Compliant
INGRESS PROTECTION	IP67 - Dust Tight, Waterproof
NAPON OSVETLJENJA (NOMINALNO)	5 ~ 28 VDC
TIP OSVETLJENJA, BOJA	LED, Cyan/Green
KARAKTERISTIKE	Finger Guide, S Symbol
ELEKTRIČNI ŽIVOT	-
DETALJAN OPIS	Pushbutton Switch SPST Capacitive, Illuminated Panel Mount, Front
CURRENT RATING	100mA (AC/DC)
BOJA - POGON / POKLOPAC	Silver
CIRCUIT	SPST
VRSTA AKTUATORA	Round, Button, Flush

Povezane oznake

Schurter CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S Distributer	Dobavljač CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S
Cijena CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S - slika	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S slika
CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S PDF list sa podacima	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S Preuzimanje tablice podataka	CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S list sa podacima
CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S Stock	Kupite CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	Kupite Schurter CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S
Schurter CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	Dobavljač Schurter	Schurter Distributer
Schurter CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	Schurter Inc. CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1019-S	

Srodni proizvodi

 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1018-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1023-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1020-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1014-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1016-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1025-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1013-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1022-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1015-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1021-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ
 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1017-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ	 CPS19-LA00A10-SNCSNCWF-RI0CGVAR-W1024-S Proizvođači: Schurter Opis: SWITCH PUSHBUTTON SPST 100MA 42V In stock: Out stock RFQ